

1:1 DVD/CD Copy Cruiser Pro HLS™

Part No. 260156

Welcome!

Congratulations on your purchase of an Aleratec 1:1 DVD/CD Copy Cruiser Pro HLS, considered by industry experts to be one of the finest DVD/CD duplicators available.

The entire Aleratec team is committed to providing you with courteous service. Our knowledgeable staff will strive to make owning and operating your new Aleratec 1:1 DVD/CD Copy Cruiser Pro HLS a pleasant experience.

This Quick Start Guide will lead you step-by step through the basic operation procedures of your 1:1 DVD/CD Copy Cruiser Pro HLS.

For more detailed information on configuring the 1:1 DVD/CD Copy Cruiser Pro HLS and applying it's various capabilities, please refer to the User Guide on the CD included.

We at Aleratec appreciate your selection of our product, and wish you great success and enjoyment of your new 1:1 DVD/CD Copy Cruiser Pro HLS.

Included Items


- 1:1 DVD/CD Copy Cruiser Pro HLS
- Power Cord
- USB Cable
- Nero Essentials CD
- Installation CD
- Quick Start Guide (this document)
- Aleratec Registration Card

Product Features

The 1:1 DVD/CD Copy Cruiser Pro HLS is a DVD/CD Duplicator and LightScribe Disc Labeler.

- Fast recording speed for high-volume copying.
- Duplicates DVDs or CDs.
- Burns LightScribe discs.

Key Items on the 1:1 DVD/CD Copy Cruiser Pro HLS



Recommended Media

CD-R LightScribe V1.2
Duplicator Grade Media
100 Pack™
Part No. 110116



CD-R LightScribe V1.2
Duplicator Grade Media
Rainbow 100 Pack™
Part No. 110117



DVD-R LightScribe V1.2
Duplicator Grade Media
100 Pack™
Part No. 230114



DVD-R 16x LightScribe V1.2
Duplicator Grade Rainbow
100 Pack™
Part No. 230115



DVD+R LightScribe V1.2
Duplicator Grade Media
100 Pack™
Part No. 300114



Summary of Operation

Your Aleratec 1:1 DVD/CD Copy Cruiser Pro HLS is equipped with a USB 2.0 port that is a bridge to the LightScribe DVDRW drive.

Stand Alone Duplicator

1. Power on your 1:1 DVD/CD Copy Cruiser Pro HLS (do not attach the USB cable), and select the Copy function by pressing the arrow buttons. Place the source disc in the top DVD/CD tray. Place a blank disc in the lower DVD/CD Recorder. After the unit detects the blank disc, press the **ENT** button to start copying.
2. When copying is completed, a good disc copy will be ejected automatically. A failed disc will remain in the DVD/CD Recorder and can be ejected manually.

Note: Detailed instructions are included in the 1:1 DVD/CD Copy Cruiser Pro HLS User Guide included on the software CD.

Disc Publishing

1. Connect the USB cable (included) to the USB port on the back of your duplicator and to an empty USB port on your computer.
2. Power on your 1:1 DVD/CD Copy Cruiser Pro HLS. The display should show:

USB	L.H. Mode
D1 Mult	D2 Mult

If you do not see this display, refer to the USB section of the User Guide.

LightScribe Disc Labeling

1. Attach your DVD/CD Copy Cruiser Pro LS to the PC via the included USB cable. Ensure that the USB option has been enabled using the steps in Read Me First.
2. Power on the machine. Please refer to the "Read Me First" instructions regarding switching from Stand Alone to USB Modes.
3. Install the Nero OEM Suite and LightScribe drivers from the included discs. Please note that LightScribe support is only available on systems running Windows 2000 SP4 (or higher), Windows XP and Windows Server 2003.
4. Place a LightScribe-certified disc with a blank label (label side down, data recording side up) in the DVD/CD recorder/disc labeler.
5. Launch the Nero software and you should find "Print LightScribe Label" in Nero SmartStart under the Extras section. Alternatively, open Nero Express, select the DVD/CD Recorder associated with your DVD/CD Copy Cruiser Pro LS from the drop-down list, then click on "Print LightScribe Label."
6. Select a label type, design your label, and then print it.

External DVD/CD Recorder

1. Install the included Nero Burning software (and USB drivers if you are using Windows 98 SE) and attach DVD/CD Copy Cruiser Pro LS to your PC via the USB 2.0 cable included (Please see "Read Me First").
2. Launch the Nero software and select the desired recording function. Insert appropriate media into the DVD/CD-Recorder and follow the steps on the display to record.

Technical Support Addresses and Phone Numbers

- By e-mail: support@aleratec.com
- By Telephone: **1-818-678-0484**

Technical Support Group can be reached 8:00 AM to 5:00 PM, Pacific Time, Monday through Friday, excluding U.S. holidays. Please try to call from a phone near your computer system.

- Access is available 24 hours a day, 365 days a year, via:

The World Wide Web at: www.aleratec.com
FAX at: **1-818-678-0483**